



# Lightahead DV328 Battery Replacement

This guide will explain how to replace the battery in the Lightahead DV328 camcorder

Written By: Alexandra McMurray



## INTRODUCTION

We will be replacing the 3.7V/900MA re-chargeable Lithium Battery in the camcorder.

## Step 1 — Battery



- The first step will require you to take off the cover where the battery will be located under

## Step 2



- You will then see the battery and a strap coming out from underneath it

## Step 3



- Pull this strap upward and the battery will pop right out
- You will then be able to replace the battery as needed

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 04:13:54 AM.